

# FABRIC REPAIR INSTRUCTIONS

Kit contains: Fabric fibers, Clear dry adhesive, applicator screen, backing fabric, spatula, mixing cups and color mixing guide.

*Always make a practice repair on a fabric sample before making an actual repair.*

Clean the damaged area with household cleaner. Trim any loose threads.

If padding is missing beneath the damaged area and the area is depressed, spread cotton balls/cotton batting evenly under the damage to build it back up.

1. Using the color match guide, pour the desired combination of colors into the empty mixing container (The container with the metal mixing ball). Shake the container 30-45 seconds to blend the fibers. Repeat as necessary until you have achieved your color match.
2. Cut the enclosed piece of backing fabric so that it is slightly larger than the damaged area. Insert the fabric into the damage and arrange so that it covers the damaged area from the inside.
3. Using the spatula, apply the clear dry adhesive onto the damaged spot. Fill the damage as evenly as possible, covering it entirely. For best results, allow to dry before proceeding to the next step.
4. Apply a thin layer of clear dry adhesive to the area to be repaired. Take the screen applicator and pour a small amount of the colored fiber mixture onto it. Hold the screen directly above the damage and gently shake. This will sift the fabric fibers onto the clear dry adhesive.
5. Cover the adhesive completely with the fabric fibers. Use the spatula to pack the fibers down into the damage, and to duplicate the patterns in the fabric. Allow several hours to dry before blowing off any excess fibers.

If the repair is not as blended as you would like, repeat step 4, and immediately apply the fabric fibers. Blow off the excess fibers and allow to dry.

Fabric fibers will only stick to the areas that have the clear dry adhesive applied.

If your fabric has a pattern with different colors, apply the clear dry adhesive in the same direction or pattern, and apply the fabric fibers one at a time (allowing to dry in between colors) until the pattern is complete.

**Repair Products Unlimited, Inc.** 1021 Evans Ave., Akron Oh. 44305

Phone: 330 798-0441 Fax: 330 798-0447

Email: [liqleather@aol.com](mailto:liqleather@aol.com)

Website: [www.repair-it-all.com](http://www.repair-it-all.com)

