

VINYL FLOOR AND TILE INSTRUCTIONS

Kit contains: 7 intermixable repair compounds, grain paper pack, powdered hardener, clear repair compound, spatula, heat tool and instructions.

Clean the damaged floor with a common household cleaner. Scrape off and clean any dirt or uneven parts of the floor.

The colored compounds in the kit are intermixable. Mix the color desired by using the chart on reverse side. (remember the color will darken after heating) After your color is mixed add ½ part powdered hardener to the colored compound and mix.

Apply the colored compound with spatula into the damaged area as evenly as possible, removing any excess compound from the undamaged area. Even application of the compound is very important.

Select a grain paper in your kit (stamped this side up). This will give a texture pattern to your repair. Draw an X in the middle of the grain paper. Place the grain paper with the X directly in the center of your repair. With a home iron or electric stove, heat the heat tool for 5 minutes on a medium high setting. Use a home iron for a larger repair. Place the heat tool on the X and hold still for 2-3 seconds. Move slowly in a circular motion then hold still again repeating this process for approximately 2 minutes. Remove the heat tool and allow the grain paper to cool. Peel the grain paper off. Examine the repair. If necessary, the damage can be refilled and reheated again to fill any under filled spots.

A common floor wax may be applied to the finished repair after it has cooled.

A professional heat tool can be purchased from Repair Products Unlimited at the above number or visit our website.

Repair Products Unlimited, Inc. 1021 Evans Ave., Akron OH. 44305

Phone: 330 798-0441 Fax: 330 798-0447

Email: Liqleather@aol.com

Website: www.repair-it-all.com